5.4 Aux Input

1. Connect an auxiliary device using a standard audio cable with 3.5 mm jack to the aux input.
2. You can now use the system as an amplifier.

5.5 Using the System

1. Make sure the system is fully charged for the best results.
2. Turn the volume control fully anticlockwise and switch on the system.
3. Gradually increase the volume to the desired level.
4. Disconnect the microphone and switch off after use.

6. Cleaning and Maintenance

Occasionally wipe with a damp cloth to keep it looking new. Do not use harsh chemicals, cleaning solvents or strong detergents.

7. Technical Specifications

power supply	DC 9V 1.0A (adaptor incl.)
operating voltage	7.4 V
battery	Li-ion 7.4 V, 1000 mAh
battery operating time	± 6-8 h
battery charging time	± 6-10 h
output	5 W @ 4 Ω
frequency response	100 Hz – 13 kHz
dimensions	85 x 85 x 50 mm
weight	265 g

DynaTech

BS-30

USER MANUAL



Thank you for choosing our products. Please do read this manual carefully before use.

USER MANUAL

PORTABLE PUBLIC ADDRESS SYSTEM

1. Introduction

Important environmental information about this product
This symbol on the device or the package indicates that disposal of the device after its lifecycle could harm the environment. Do not dispose of the unit (or batteries) as unsorted municipal waste; it should be taken to a specialized company for recycling.

Thank you for choosing DynaTech ! Please read the manual thoroughly before bringing this device into service. If the device was damaged in transit, do not install or use it and contact your dealer.

2. Safety Instructions

Read and understand this manual and all safety signs before using this appliance.

Indoor use only.

Power supply polarisation.

This device can be used by children aged from 8 years and above, and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the device in a safe way and understand the hazards involved. Children shall not play with the device. Cleaning and user maintenance shall not be made by children without supervision.

The internal battery is not replaceable.

3. General Guidelines


All modifications of the device are forbidden for safety reasons. Damage caused by user modifications to the device is not covered by the warranty.

Only use the device for its intended purpose. Using the device in an unauthorised way will void the warranty.

Damage caused by disregard of certain guidelines in this manual is not covered by the warranty and the dealer will not accept responsibility for any ensuing defects or problems.

Nor DynaTech nor its dealers can be held responsible for any damage (extraordinary, incidental or indirect) – of any nature (financial, physical…) arising from the possession, use or failure of this product.

Keep this manual for future reference.



4. Overview

Refer to the illustrations on page 2 of this manual.

1	charge indicator
2	power indicator
3	microphone input

4	aux input
5	volume control
6	on-off switch

5. Operation

5.1 Charging the Battery

This device contains an internal rechargeable battery. When the device reaches end-of-life, it must be disposed of in accordance with local regulations.

Please charge the system when the LED is dim. To do so:


1. Make sure the system is switched off.
2. Connect the system to the mains using the power adapter.
3. The LED will turn green as soon as the battery is fully charged. Do not overcharge and disconnect from the mains after charging is complete.

5.2 Wearing the System

Fix the system to your waist using the included belt.

5.3 Using the Microphone

1. Connect the included microphone to the system.
2. Slide the microphone set over your head and wear it as illustrated. Place the microphone at a distance of 20-30 mm from your mouth.



3. Talk into the microphone. Use the same full voice you would normally use to be heard in a conversation.